

CARE-FLARE® User Manual

1 To activate CARE-FLARE:

Note: When activated, CARE-FLARE has two available light sequences:

- Alternating red and white flashing
- Continuous red

1. Click on the top button to activate, change sequence and turn off CARE-FLARE



- 1st click = First light sequence is activated
- 2nd click = CARE-FLARE is turned off
- 3rd click = Second light sequence is activated
- 4th click = CARE-FLARE is turned off

2 To stand up CARE-FLARE:

1. Open CARE-FLARE's legs by pulling each of the legs away from the body



2. Stand-up CARE-FLARE in a triangular stance



3. When finished, close both legs by pushing them towards the body




3 To replace batteries in CARE-FLARE:


Note: When it is time to change the batteries, the light sequence will change to slow flashing red.

To replace batteries:


1. Locate end cap at bottom




2. Unscrew the end cap



3. Remove the end cap



4. Insert four C batteries, + side towards top, - side towards bottom



5. Screw end cap back into place

